

REVEL ROUND

REVEL ROUND CARE INSTRUCTIONS

Revel Round roundboards are made out of birch plywood. Texture directions and knots are part of wood's nature and charm, and no two pieces are alike. The wood will continue to change throughout the product's life span. It's important to handle & care correctly:

CARING FOR YOUR REVEL ROUND GAME SET:

- Do not stand on your Revel Round set
- Do not sit on Revel Round if weight exceeds 275lbs.
- Wood may expand and shrink with differences in temperature and humidity. Keep your set at least one meter away from a direct source of heat (heaters, radiators, fireplaces etc.).
- Extended direct exposure of your Revel Round to sunlight may lead to loss of the original color and could lead to deformations.
- Remove spilled liquids from wooden surfaces as soon as possible.
- Cleaning is carried out with a clean, dry, lint-free cloth from cotton or another material, then drying it with a clean lint-free cloth. We do not recommend microfiber cloths.
- Do not remove any parts or hardware
- Do not stack things on top of Revel Round set
- Avoid dragging sharp or rough objects across the surface of your Revel Round.
- Always secure legs when storing.
- Do not over stretch shock cords in the legs it will greatly decrease snap and board stability.
- If round bags get wet that's okay they typically air dry 8-12 hours

We understand things can happen when playing. If you're Revel Round set has an issue please visit our website and fill out the Service Request form so we can provide you with the best assistance possible.



PLAY-LIFE NATION